



Slurry-Busta Pump

1. Cover / Lock
2. Bearing Housing
3. Top Frame Assembly
4. Spacer
5. Spacer Ring
6. Bearing 22313C
7. KM13 Nut
8. MB13 Washer
9. Labyrinth Cover
10. Sealing Ring
11. Bearing NU314
12. Circlip
13. Lower Frame Assembly
14. Casing Cover
15. Back Liner
16. Impeller
17. Volute Casing
18. Shaft
19. Seal V60
20. Seal V90